

Mast Tuning Guide Hanse 370

TWS (True wind speed)	Headstay turnbuckle	Rake cm	V Using Tension Gauge	D1. Using Tension Gauge	D2. Using Tension Gauge	Mast Butt pos. cm (J measurement)
0-30	NA	223-225	40	25	16	415
			Use Loosegauge model: PT-3m	Use Loosegauge model: PT-3m	Use Loosegauge model: PT-3m	

Rig setup

1. Deck position for mast: Centerline intersection deck/forestay to forward edge mast = **415** cm (J. measurement)



2. Headstay datum: Top bas swing to forestay with center halyard to forestay



Better by Design

3. **Mark your forestay** and use that as reference mark.



4. **Measure** from mark on forstay to the intersection deck/forestay.
This setting should be: **223-225 cm**.



Inventory by North Sails
Better by design